



M632

UPDATED MIST TVCT PLAN

Document ID:

M632-033

Version:

1

Issue Date:

10 February 2022

Document Type:

DRAFT

Valid from:

Review

Prepared by:

.....
Sven Grahn/ MM

Reviewed by:

.....
List reviewers

Distribution: DropBox,



Change Record

Version	Date	Changed paragraphs	Remarks
1.0	2022-02-10	-	New Document

Abstract: -This document contains the ...

Keywords: - AAAA, BBBB

Table of Contents

1	TEST PURPOSE AND BASIC PRINCIPLE.....	4
2	TEST SETUP.....	5
2.1	Test article mounting in Thermal Vacuum Chamber.....	5
2.1.1	Location in chamber.....	5
2.1.2	Suspension system.....	5
2.2	Test article mechanical configuration.....	6
2.2.1	Subsystems.....	6
2.2.2	Experiments.....	6
2.2.3	Solar panels & cover plates.....	6
2.3	Test article instrumentation.....	7
2.3.1	Thermocouples.....	7
2.3.2	Other temperature sensors.....	8
2.4	Test support systems.....	8
2.4.1	Umbilical.....	8
2.4.2	Heaters.....	10
2.5	Location of the control of the test.....	14
2.6	Control functions from the ground support equipment.....	14
3	OVERALL TEST SEQUENCE AND EXECUTION.....	15
3.1	Pre-test preparation sequence.....	15
3.2	Temperature settings.....	15
3.3	Step-by-step test procedure.....	16
3.3.1	Test programming.....	18
3.3.2	Functional testing.....	18
4	PRE-TEST SIMULATIONS.....	19
4.1	Thermica Model and User File.....	19
4.2	Temperature, Heater, and dissipation settings.....	19
5	POST TEST ANALYSIS.....	19
6	REFERENCES.....	21
6.1	Reference Documents (RD).....	21
6.2	Appendices.....	22
6.2.1	Unit temperature limits.....	22
6.2.2	Internal dissipators used in test simulation.....	22
6.2.3	Illustrations related to the test procedure.....	23
6.2.4	Experiment and subsystem temperature sensors.....	27
6.2.5	Simulation Results.....	28



1 TEST PURPOSE AND BASIC PRINCIPLE

The aim of the thermal vacuum cycling test is to test the hardware and the functionality of the systems. During the test, the satellite experiences vacuum and rapid temperature transitions from its maximum heat to its lowest cold limits. During the test function tests are performed to make sure the systems of the satellite performs as expected.

This document serves as a report of the work of planning the thermal vacuum cycling test. It is structured as a test. The goal has been to plan the vacuum cycling test and present it in a clear and structured document which can be easily understood when the time for testing comes.

Note! Updates to the document may be necessary when more details of the test are decided. Especially the temperature settings may require changes when the functional testing plan is finished.

2 TEST SETUP

2.1 Test article mounting in Thermal Vacuum Chamber

2.1.1 Location in chamber

Once in the chamber, MIST should be suspended according to the specifications provided in document M632-020 regarding heater locations and heights (Figure 1).

The suspension device must comply with the TVAC internal dimensions. It is still unclear if the table in the chamber could be helpful or an impediment during the satellite positioning. The device is designed to have adjustable hanging wires lengths. With the current specifications MIST is positioned almost in the centre of the chamber. If the table is removed the wires can be adjusted accordingly.




Figure 1 Heater locations over TVAC table

2.1.2 Suspension system




Figure 2 Location in TVAC of the satellite.

The device is suspended and connected to the TVAC ceiling rail with two rollers. One roller was enough for the purpose of suspending MIST, but this solution allows to have only one

degree of freedom for the whole system. The suspension device can only move along the rail and will not swing back and forth during MIST positioning.

The eye nuts are positioned at the corner of a 100 mm side square, as the wire mount hinges of MIST. It is true that this make the device specific for MIST, but it is also unlikely that a future project will have a considerable larger size.

Moreover, if the cross section of a future project is symmetric and the mass comparable to the one of MIST, it will not be a problem if the hanging wires are not extending in a completely vertical configuration.

Thermal insulation between the satellite and the suspension device is necessary to prevent, or at least reduce, thermal exchange that could alter the test results.

The critical interface is between the wire mount hinges and the hanging wire. A thermally insulating washer is necessary at the mock solar panel hinges. In addition, also the wires could be insulated, for instance using Kapton tape.

This configuration is easy to set up and there is no direct interface between the hanging system and the satellite. The suspension system design is described in [RD1].




Figure 3 TVAC suspension system.

2.2 Test article mechanical configuration

2.2.1 Subsystems

- All subsystems shall be installed.
- All subsystems shall be turned ON except the AntS. (TBD).
- The TRXVU shall not transmit, and its function replaced by the TRXVU simulator.

2.2.2 Experiments

- All experiments shall be installed.
- All experiments shall be turned ON during the test. The level of operation is TBD but their heat dissipation shall be reflected in the modelling of the test.
- NanoProp shall NOT be filled with propellant.

2.2.3 Solar panels & cover plates

- Dummy solar panels will be used including the deployable panels
- Deployed dummy solar panels will be attached by fixed brackets.
- Surface treatment: the dummy solar panels shall be black anodized.
- The top and bottom cover plates shall be flight units and be black anodized (TBD).

2.3 Test article instrumentation

2.3.1 Thermocouples

The thermocouples placements are the same as for the thermal balance test. During TVCT they are used only to make sure the satellite does not get too cold or too hot. Thermocouples will be Welded Tip PFA Thermocouples from TC Direct, Article 401-324, a type T thermocouple with 0.2 mm diameter (AWG 32) wires and equipped with a plug.

2.3.1.1 Thermocouple mounting

The methods for attaching of the thermocouples are set out in the document M632-030.

2.3.1.2 Thermocouple location

Table 1, Figure 4 and Figure 5 are taken directly from [RD5]. Figure 6 shows the thermocouple locations in three dimensions. The thermal model meshing is also shown in this figure. The thermocouples should probably be placed not too far from the centre of each mesh element.

Thermocouple #	Component and node	Interface
Top Stack		
1	Dummy Plate 114	1
2	Top Cover Plate 528	1
3	Dummy plate 7500	2
4	Hexnut 727	2, 3
5	Rib 625	3, 4
6	Rail 401	4
Bottom Stack		
7	Bus Spacer 752	5
8	Bus Spacer 738	5
Integrated sensor #		
101-106	NANOPROP 1-6	ON
107-108	CUBES 1-2	OFF
109-113	LEGS 1-4	OFF
114-115	SIC 1-2	ON
116	SEUD	ON

Table 1 Thermocouple placement and respective interfaces, and sensors




Figure 4 Top stack with approx. TC placements




Figure 5 Bottom stack with approx. TC placements




Figure 6 3-D locations of thermocouples.

2.3.1.3 Thermocouple readout

The regular temperature display system of the TVAC shall be used to read out thermistor temperature values.

2.3.2 Other temperature sensors

See section 4.2.5 in the Appendices for a list of experiment and subsystem sensors.

2.4 Test support systems

2.4.1 Umbilical

The umbilical shall be used to communicate with MIST satellite while in the thermal vacuum test chamber. The umbilical shall connect to the satellite's umbilical connector (a.k.a. the

ABF connector location) on one end and to the EPS-EGSE on the other end – outside the tank. For more details see [RD4].

2.4.1.1 Umbilical routing

The umbilical is split into two parts.

Part 1: Omnetics A28000-037 to D-SUB 37 connector (socket). This is basically the standard ISISPACE umbilical built around the connector plus pigtails and is spliced with a cable to terminate at a D-SUB 50 connector (pin). Length: 1300 mm (L1 in Figure 6).

Part 2: A cable that connects the 50-pin connector on the outside tank wall to the EPS-EGSE. Length: 1600 mm (L2 in Figure 6).




Figure 7 Umbilical routing from satellite to EPS-EGSE.

2.4.1.2 Satellite control via the umbilical

- **Inhibitions of deployments:** The AntS and HDRM deployments are inhibited since the ABF connector is not attached. The umbilical connector does not “arm” these functions.
- **Powering on the satellite:** The “kill switch” is activated via the umbilical and the EPS-EGSE which is connected to the umbilical outside the tank. Activating the “kill switch turns on the power system” of MIST.

- **Sending commands and receiving telemetry:** Subsystems and experiments are controlled during the test by using the TRXVU simulator. The TRXVU simulator (Arduino-based) is connected to the umbilical outside the TVAC via the EPS-EGSE and commands are sent to the TRXVU from “TestStand” **(TBC)**.



Figure 8 Completed umbilical. Coloured part is the section inside the TVAC.

2.4.2 Heaters

2.4.2.1 Heater locations

The location of the heaters is shown in Table 3 and Figure 8. Please note that the outline of experiments in the part of the satellite outer surface not covered by solar panels is obsolete, but this has no effect on the location of the heaters. The location of the heaters during the TVCT are the same as during the Thermal Balance Test





Figure 9 Heater locations.

Location	Config.	Schematic	Heater placement
Top cover plate	2s	1	+Z (one each along +X,-X side of plate)
Bottom cover plate	2s	1	-Z (one each along +X,-X side of plate).
Side cover plates	2s/2p	2	-X,+X,-Y,+Y, just above Antenna/HDRM.

Table 2 Heater locations table.

2.4.2.2 Heater circuit connections



The top and bottom cover plate heaters are just two heaters in series. The “mid-stack” or “mid-section” heaters are connected two pairs in series that are connected in parallel. “Minco” stands for “Minco heater”

Figure 10 Electrical connection of heaters.

2.4.2.3 Heater harness and patch panel

The heater harness connects the heaters on the satellite to power supplies on the outside of the tank. The way the heaters are connected to power supplies is shown in Figure 10.




Figure 11 Mid-section heaters and patch panel

The detailed specification of pin assignment in the heater harness is set out on [RD2]. The detailed design of the patch panel is described in [RD3].

2.4.2.4 Heater installation

- **Pre-assembly:** The heater harness and heater elements shall be pre-assembled as set out in [RD2].
- **Heater attachment:** The heaters shall not be attached to the dummy body solar panels until just before the satellite is placed in the TVAC.
- **Heater “burn-in”:** Heaters may be “burned” in by applying power to them for a short time – before the TBT commences. **TBD**.
- **Heater shelf life** [See RD2].

2.4.2.5 Heater and wire data needed to compute settings of power supplies.

- **Harness wire gauge:** AWG 22 (0.38 mm^2): $4.6 \Omega/100 \text{ m}$.
- **Harness wire length:** 2.7 m (**TBC**)
- **Heater type and resistance:** Minco HK6907, 47.78Ω .




Figure 12 Heater harness.

2.4.2.6 Heater temperature settings during the TVCT

The heater placement will be the same as for the thermal balance test. During the TVCT the heaters make sure that no system gets too cold during the cold phases of the testing. Table 4 shows an overview of the heater settings. More detailed settings are shown in document MIST_M632_012_version_1_20210122_Thermal_Vacuum_Cycle_Test_Settings.

Table 3: Overview of the heater settings.

SHROUD TEMPERATURE	-50 C	-25 C	0-45 C
TOP HEATERS – MAX 10,6 W	1.5 W	1.5 W	0 W
MID HEATERS – MAX 21,2 W	0 W	0 W	0 W
BOTTOM HEATERS – MAX 10,6 W	2 W	0 W	0 W
BATTERY HEATER	3 W	3 W	0 W

The battery heater is supposed to be automatic and turn on when the battery temperature is below 0 and turn off when it is above. The added heaters are controlled manually by adjusting the voltage.

2.4.2.7 Internal heaters

The internal heaters are:

- NanoProp Tank heater– max power 1.4 W (used to supply extra heat in NanoProp **is that OK?**)
- NanoProp Thruster heaters– max power 4 x 0.25 W (**Can/will these be used? TBD**)
- Battery max power – 3.5 W (kept as a safety heater, **TBD**).

2.4.2.8 Safety monitoring of heaters

To avoid the risk of heaters disconnecting from the cover plates and overheating thermocouples could be connected to the cover plates and monitored through the normal

TVAC temperature display system. On the $\pm Z$ cover plates it is proposed that only one thermocouple is used to check if the temperature of the cover plate suddenly drops during the test. On the mid-stack there should be a safety thermocouple near each heater. Figure 13 shows these approximate locations for the -Z cover plate and the mid stack. On the +Z cover plate there is also only one safety thermocouple.

2.5 Location of the control of the test

- Thermocouple monitoring will be done in the room just outside the TVAC room.
- Control of the heaters needs to be made close to the TVAC unless a very long cable connects the heater patch panel to the heater harness. **(TBD)**
- Control of the satellite and monitoring of internal temperature sensors needs to be performed via the laptop connected to the EPS-EGSE and the TRXVU simulator. This computer could possibly be remotely controlled from the room just outside the TVAC room. **(TBD)**

2.6 Control functions from the ground support equipment

- Turn experiments and subsystems ON/OFF.
- Set operations mode of experiments by command.
- Command heaters in NanoProp and BP4 Battery Pack ON/OFF.
- Perform functional testing of subsystems/experiments (including collection of temperatures and housekeeping data from experiments and subsystems at **TBD** intervals and **TBD** times) as per Table 3.




Figure 13 Locations of safety thermocouples.

3 OVERALL TEST SEQUENCE AND EXECUTION

3.1 Pre-test preparation sequence

Step	Details in	Description
1	MAM ¹	Assemble MIST according to [RD6] excluding the cover plates.
2	MAM	Attach thermocouples to assigned components described in section TBD .
3	This doc.	Take photo of attached thermocouples and thermocouple ID for documentation
4	MAM	Attach cover plates to MIST.
5	MAM	Attach heaters on designated locations.
6	This doc.	Take photo of heaters attached for documentation
7	MAM	Attach heater harness (spider part) to internal & external feedthrough flanges.
8	This doc.	Connect heater harness to the power supply.
9	MAM	Attach MIST to the TVAC suspension device
10	MAM	Attach the TVAC suspension device to the rail in the top of the TVAC.
11	MAM	Connect heater "spider heater harness" to heater circuits.
12	This doc.	Perform a burn in test with the heaters. TBD
13	MAM	Install and connect the umbilical cable (part 1, see 2.4.1.1)
14	This doc.	Install the umbilical cable (part 2, see 2.4.1.1) to the TVAC and the EPS-EGSE
15	This doc.	Perform communications test with MIST

3.2 Temperature settings

The difference between the maximum and minimum temperatures during the TVCT is approximately 60 degrees depending on which system one looks at. This was chosen according to the limits in temperature range and that it is approximately the range used by other similar projects. Table 1 shows the current temperature requirements of the satellite's subsystems and experiments.

The operative temperature means that at these temperatures the systems should perform as expected and required. Exceeding these temperatures, the performance may suffer. Exceeding the non-operative temperature limits may cause damage to the systems and should therefore be avoided. At the operative temperatures functional tests can be performed.

	NON OPERATIVE		OPERATIVE	
	Min	Max	Min	Max
TRXVU	-40	60	-40	60
SOLAR PANELS	-40	100	-30	70
BATTERY	-5	45	-5	45
EPS	-40	85	-40	85
IGIS	-30	70	-30	70
ANTENNA	-50	85	-20	60
MAGNETORQUER	-40	70	-40	70
OBC	-40	80	-25	65
CAMERA	-40	95	-30	70
SIC	-40	105	-40	105
SEUD	-65	150	0	85
NANOPROP	-10	50	0	50

¹ Mechanical Assembly Manual [RD6]

LEGS	-30	70	10	40
CUBES	-20	60	-20	30

Tabell 1 Temperature requirements of subsystems and experiments.

The test proceeds by setting the temperatures of different maximum and minimum limits. As shown in Figure 14, the test sequence starts by several temperature plateaus where functional tests can be performed according to Table 2. At each level different systems can be tested. After the functional testing there are an additional two cycles between the maximum and minimum temperatures. When the cycles are completed a final functional test can be performed at room temperature.




Figure 14 The temperature of the vacuum chambers shroud during TVCT

During the transitions, a larger or smaller temperature than the target temperature is initially set. This is to speed up the transitions between the temperature levels. This reduces the time required for the test as well as putting added stress to the hardware which is good during the test. The maximum transition speed is however limited by the vacuum chamber to 1.5 degrees/minute.

3.3 Step-by-step test procedure

Step	Description
1	Start computer controlling the vacuum chamber and start WinKratos.
2	Close vacuum chamber door.
3	Start the logging of temperature and pressure in WinKratos. Enter desired name on the log file and hit "Start data acquisition". (Figure 13)
4	Open charts and display attached thermocouples. Mark desired channels for thermocouples. Two different chart sections can be made to separate the curves into the two different sections) (Figure 14)

Step	Description
5	Open Probe windows for current temperature readings of attached thermocouples. Open enough windows to show all necessary temperature readings and configure the different probe windows to show the correct channels for desired thermocouples. (Figure 15).
6	<p>Turn on vacuum pumps. Set Primary vacuum pumps to ON. Set Primary vacuum valve to ON. Set Turbo pump to ON. Set High vacuum turbo to ON. Hit “Execute”. (Figure 15). Set all four pumps to ON at once. The Primary pumps will warm up for approximately 20 minutes before they start working. Once the pressure reaches 10^{-2} the turbo pump will start warming up for 5 minutes before starting.</p> <p>When the left box is yellow, the command is recognized and when the right box is green it is active. The right box for “Primary vacuum pump” and “Primary vacuum Valve” will be green when above 10^{-2}, after that the turbo pump will take over.</p>
7	Wait until pressure is below 10^{-5} mbar.
8	Start subsystems and experiments in MIST. <u>Start sequence TBD</u>
9	Start recording internal sensor temperatures. <u>Start sequence TBD</u>
First temperature setpoint – shroud temperature 10°C	
10	WinKratos commands temperature setpoint for the vacuum chamber to 10°C. Check correct functioning of: LEGS .
Second temperature setpoint – shroud temperature 0°C	
11	WinKratos commands temperature setpoint for the vacuum chamber to 0°C. Check correct functioning of: SEUD, NanoProp .
Third temperature setpoint – shroud temperature 30°C	
12	WinKratos commands temperature setpoint for the vacuum chamber to 30°C. Check correct functioning of: CUBES 1 and 2 .
Fourth temperature setpoint – shroud temperature 40°C	
13	WinKratos commands temperature setpoint for the vacuum chamber to 40°C. Check correct functioning of: LEGS .
Fifth temperature setpoint – shroud temperature 45°C	
14	WinKratos commands temperature setpoint for the vacuum chamber to 45°C. Check correct functioning of: TRXVU, BP4, EPS, IGIS, AntS, iMTQ, iOBC, Camera, SIC, SEUD, NanoProp .
Sixth temperature setpoint – shroud temperature -25°C	
Sixth temperature setpoint– shroud temperature to room temperature	
15	WinKratos commands temperature setpoint for the vacuum chamber to room (ambient) temperature. Check correct functioning of: All units .
16	When shroud has reached ambient temperature wait one hour.
17	Shut down logging.

Step	Description
18	Convert logfile to ASCII for data handling. (Figure 17). Enter "Col. Selection": mark all the thermocouple channels used Hit "Start conversion"
19	Save both log files and converted ASCII files to MIST backup drives

3.3.1 Test programming

A WinKratos program will be used for the TVCT. This runs the thermal and vacuum control of the vacuum chamber, and the test sequence should be programmed. At the times of functional testing, it might have to be paused depending on how the testing is done. It would however be optimal if the test could be run by just starting the sequence and then let it run. The test programme is added to appendix 7.1.

3.3.2 Functional testing

During the TVCT functional tests should be performed. This must be coordinated with the Functional testing team. The optimal solution would be to have a test programme which can be run automatically at specified times.

Functional testing is performed at -25, 0, 10, 30, 40, and 45 degrees for different systems. Maximum non-operational temperature is 45 degrees. Minimal non-operational temperature is -25 degrees. The dwell time is two hours. More specific information of each subsystem and experiment is shown in Table 3 Summary of the systems and experiments tested during TVCT. This table should be made into a separate document and filled in during/after the test.

SUBSYSTEM/EXPERIMENT	MOUNTED DURING TEST	TESTED AT SHROUD TEMPERATURES	RUN TIME	HOW IT IS TESTED	RESULTING DATA
TRXVU	Yes	-25, 45		No RF applied or sent.	
SOLAR PANELS	No	-	-	-	-
BATTERY	Yes	-25, 45		Separate document?	
EPS	Yes	-25, 45		Separate document?	
IGIS	Yes	-25, 45		Separate document?	
ANTENNA	Yes	-25, 45		Separate document?	
MAGNETORQUER	Yes	-25, 45		Separate document?	
OBC	Yes	-25, 45		Separate document?	
CAMERA	Yes	-25, 45		Separate document?	
SIC	Yes	-25, 45		Separate document?	
SEUD	Yes	0, 45		Separate document?	
NANOPROP	Yes	0, 45		Separate document?	
LEGS	Yes	10, 40		Separate document?	
CUBES	Yes	-25, 30		Separate document?	

Table 4 Summary of the systems and experiments tested during TVCT.

4 PRE-TEST SIMULATIONS

The simulations of the TVCT are made to make sure that the temperature requirements are fulfilled and that the functional testing is performed at the required temperatures. The current results show that the limits are fulfilled and that the testing can be performed at the appropriate temperatures. There are however some details left to implement.

- The simulations should be updated with the expected dissipation from the functional testing.
- The model in Systema can be updated with more accurate measurements of absorption and emissivity.
- The WinKratos test program should be written.

Plots of the results are added to appendix 7.2.

4.1 Thermica Model and User File

The following files have been used in the simulations of the TVCT. The major differences between the model used during thermal tests and the model used in space environment simulations are that the vacuum chamber is added and that the antennas are not deployed. The solar panels are also replaced by dummy plates during testing, but the aim is to have them as similar as possible to the actual solar panels. There are no changes between the model used for TBT and TVCT.

Table 5: List of all the files used in the simulations of the TVCT.

USE	FILE NAME
MODEL	MIST_v9_0_SPHERE.sysmdl
MESHING	MIST_v9_0_SPHERE.sysmsh
MISSION	MIST_v9_0_SPHERE.sysmdl
PROCESSING	MIST_v9_0.sysprc
USER FILE	MIST_v9_0.nwk
TMM-FILE	TMM_v8.0_TitaniumScrewsNutsWashers.xlsx
SETTINGS	MIST_M632_011_version_1_20210122_Thermal_Vacuum_Cycle_Test_Settings.xlsx

4.2 Temperature, Heater, and dissipation settings

The chambers temperature setting, heater effects and systems dissipations are specified in the following document for each time step:

MIST_M632_012_version_1_20210122_Thermal_Vacuum_Cycle_Test_Settings

5 POST TEST ANALYSIS

From a thermal viewpoint there is not much need of a posttest analysis of the TVCT. The analysis should instead be focused on evaluating the systems testing to make sure everything worked. If something did not work as intended, it should be studied to explain why this is. If it does not work during TVCT it will most likely not work in space.





6 REFERENCES

6.1 Reference Documents (RD)

RD#	Document Title
1	M620-002 MIST TVAC Suspension Device
2	M632-020 Heater Harness Pre-Assembly
3	M632-025 Patch Panel Design
4	M632-016 Thermal Test Umbilical Requirements Specification
5	M632-004 Thermal Balance Vacuum Test
6	M110-031 Assembly Manual for Thermal Testing (in preparation)

6.2 Appendices

6.2.1 Unit temperature limits

	Non Operative		Operative		
	Min [C]	Max [C]	Min [C]	Max [C]	
TRXVU	-40	60	-40	60	OFF
Battery	-5	45	-5	45	ON
IGIS	-30	70	-30	70	ON
Antenna	-50	85	-20	60	OFF
IMTQ	-40	70	-40	70	ON
OBC	-40	80	-25	65	ON
Camera	-30	70	0	70	ON
SiC	-40	105	-40	105	ON
SEUD	-65	150	0	85	ON
NanoProp	-10	50	0	50	ON
LEGS	-30	70	10	40	OFF
Cubes	-20	60	-20	30	OFF

8°C safety margin applied. Time plots for each subsystem in appendix. Subsystems are simulated to be in their designated state during the entire test. They usually have a smaller acceptable temperature range when ON. Most systems ON/OFF have a small effect on even their own temperature, so the plots in the appendix are a good estimate of the possibility of switching the state of a subsystem, although a re-simulation is recommended to get good certainty on estimated temperatures [RD5]. **(Why is CUBES OFF? TBD)**

6.2.2 Internal dissipators used in test simulation.

Table 6 External/internal dissipations.

Internal Heaters/Dissipators	
OBC	0,5 W
IMTQ (Idle)	0.1 W
TRXVU (Receiver only)	0.44
NanoPower a.k.a. P31us	0.7 ² W

heater and subsystem

Experiment Dissipations	
SEUD	1 W
SIC	0.3 W
LEGS (will this be ON?)	0.4 W
CUBES (Will this be ON?)	0.9 W
NanoProp (PCB)	0,2 W
NanoProp Tank Heater	1.40 W
Nanoprop helper board ³	0.2 W

² This is assuming there is no input converter losses. This corresponds to dissipation in eclipse.

³ Efficiency 89%. So the loss when running tank heater is $1.4 \cdot (1 - 0.89 / 0.89) = 0.87$ W

6.2.3 Illustrations related to the test procedure




Figure 15 Start data acquisition.




Figure 16 Attach thermocouples.




Figure 18 Start vacuum pumps.




Figure 17 Open probe windows to check temperatures




Figure 19 Convert logfile to ASCII

6.2.4 Experiment and subsystem temperature sensors

Experiment	# of sensors	Location	Remarks
CUBES 1	2	See M120-022	-
CUBES 2	2	See M120-022	-
LEGS	1	See M120-022	Four NTC resistors in parallel.
NanoProp	6	See M120-022	Two on Tank, one each on thrusters.
SEUD	1	See M120-022	In Artix-7 FPGA
SIC	2	See M120-022	-

Table 7 Experiment temperature sensors.

Subsystem	# sensors	Location	Remarks
TRXVU	2	Power Amp., Local Osc.	-
IOBC	2	See below	-
EPS	4	Converters	Check why 4. There are only 3 converters
BP4	2	Battery	-
iMTQ	4	3 x Coils, 1 x MCU	-
AntS	2	One on each microcontr.	-

Table 8 Subsystem temperature sensors

Regarding the location of the temperature sensors on the IOBC, please see the below screenshot (Figure 20) of the iOBC revB.

- The red circled component marked U29 is the board temperature sensor. An explanation of how to translate the output voltage value into temperature values is attached to this document. The sensor is of the type LM94022/-Q1 1.5-V, SC70, Multi-Gain Analog Temperature Sensor With Class-AB Output.
- The blue circled circuit is the RTC (Real-Time Clock). It has a temperature sensor. Product number: DS3234SN# .Datasheet link: <https://nl.mouser.com/datasheet/2/256/DS3234-1514369.pdf>




Figure 20 Location of iOBC thermal sensors.


The following questions about the iOBC thermal sensors remain to be answered:

- What iOBC ADC channel is the board temperature sensor connected to (if any)?
- Is this the sensor that can be read out via the supervisor?


6.2.5 Simulation Results

These simulation results have been copied from M632-026 and may possibly updated by inserting new dissipations.


6.2.5.1 Nanoprop




6.2.5.2 SEUD





6.2.5.3 SiC




6.2.5.4 LEGS




6.2.5.5 Cubes 1**6.2.5.6 Cubes 2**


6.2.5.7 Camera




6.2.5.8 IGIS




6.2.5.9 Nanopower Board




6.2.5.10 Battery




6.2.5.11 IMTQ



6.2.5.12 TRXVU



6.2.5.13 OBC**6.2.5.14 Antenna**